

## Operation Manual



**NMEA 2000® Edition**



**Contact Beede**  
Beede Electrical  
Instrument Company, Inc.  
88 Village Street  
Penacook, NH 03303  
(603) 753-6362  
Toll-free 800-451-8255  
Fax (603) 753-6201



WWW.BEEDE.COM

## Table of Contents

About .....	1
Scope .....	1
Preconfigured Instruments .....	1
Menu Navigation .....	2
Menu/Mode/Enter/Reset Switch .....	2
Up Switch .....	2
Down Switch .....	2
Switch Icon Conventions .....	2
Selection Arrow Cursor .....	3
Blinking Bar Cursor .....	4
Start-up Screen .....	5
Default Quick View Main Screen .....	5
Quick View Main Screens .....	5
Bar Graph & Three Line Format .....	6
Trips (Hours) Screen .....	7
Resetting Trips .....	7
Main Menu .....	8
Trips .....	9
View Parameters .....	10
Setup .....	11
Mute .....	12
Faults .....	12
Warnings .....	13
Alarms .....	14
Recall .....	15
Fuel .....	16
Miscellaneous .....	17
Setup Menu .....	18
Backlight .....	18
Units .....	20
Clock Viewing & Setting .....	21
Viewing & Setting .....	21
Clock Format .....	22
Main Clock .....	23
Alarms .....	24
Enabling Alarms .....	24
Viewing Alarms .....	25
Editing Alarms .....	26
Active & All Parameters Selection Sets .....	27
Setting Quantity of Alarms .....	27
Alarm Configuration .....	28
Adding Additional Alarms .....	30
Deleting an Alarm .....	31
A/D (Analog/Digital) Inputs .....	32
NMEA 0183 Input .....	32
A/D Pressure Sender Inputs .....	33
Display .....	35
Main Order .....	35
Main Trim .....	37
Trim Screen Formats .....	37
Main Clock .....	38
Main Roll .....	38

Table of Contents

Main Recall .....39

Key Off.....40

Set Video .....41

Set Contrast.....42

Speedometer.....43

    CAN Speedometer .....43

    GPS (NMEA 0183) Speedometer .....43

Calibration- Fuel Tank.....44

    Calibration Tank 1 or 2.....45

    Setting Fuel Tank Data Source .....46

    Setting Fuel Tank Total Capacity .....47

    Calibrating Fuel Tank Level.....48

    Calibrating Fuel Tank Level Step 1 - Empty Tank.....48

    Calibrating Fuel Tank Level Steps 2 thru 5 .....49

    Resetting Fuel Tank Calibration .....50

    Viewing Calibration Steps .....50

    Viewing Calibration Steps 2 thru 5 .....51

    Saving Fuel Tank Calibration Data.....52

    Tank Display .....52

Calibration - Engine Trim.....53

    Selecting Engine Trim Sender Type for Calibration .....54

    Calibrating Full-Down & Full-Up Trim Sender Positions.....55

    Viewing Trim Calibration Settings.....56

    Saving Trim Calibration Settings .....57

Set Popup.....58

    Trim Popup Function .....59

    Popup Menu .....60

    Enabling/Disabling Popup Features.....60

Set CAN Bus .....65

    Multiple Engine Applications .....66

    Single Engine Applications .....66

    Setting SAE J1939 Engine Number.....67

    Setting SAE J1939 Default Quick View Main Screen 1 (Total Hours or Miles).....68

    Setting Master Node Instrument Instance Number (SAE J1939) .....69

    Setting NMEA 2000® Engine Number .....70

    Setting NMEA 2000® Default Quick View Main Screen 1 (Total Hours or Miles) .....71

Analog Input Parameters Table ..... 72

NexSysLink® Implementation of NMEA 2000® Parameters ..... 73

NexSysLink® Implementation of SAE J1939 Parameters ..... 75

Parameter Icons & Descriptions ..... 78

Menu Navigation Icon Descriptions ..... 81

Notes ..... 82

## List of Figures

Figure 1-1: Menu Scrolling and Option Selection .....	3
Figure 1-2: Blinking Bar Cursor .....	4
Figure 1-3: Quick View Main Screens .....	5
Figure 1-4: Setting Parameter View Display Format .....	6
Figure 1-5: Resetting Trip (Hour) Logs .....	7
Figure 1-6: Accessing the Main Menu .....	8
Figure 1-7: Accessing Trip Logs from the Main Menu .....	9
Figure 1-8: Viewing Parameters .....	10
Figure 1-9: Accessing the Setup Menu .....	11
Figure 1-10: Fault Notification & Information Screens .....	12
Figure 1-11: Quick View Main Screen with Warning “W” Icon .....	13
Figure 1-12: Warning Notification and Information Screens .....	13
Figure 1-13: Quick View Main Screen with Alarm “Bell” Icon .....	14
Figure 1-14: Recall Function .....	15
Figure 1-15: Fuel Management Function .....	16
Figure 1-16: Miscellaneous Functions Menu .....	17
Figure 1-17: Setup Menu Functions .....	18
Figure 1-18: Setting Backlight Intensity .....	19
Figure 1-19: Setting Units .....	20
Figure 1-20: Clock Viewing and Time/Date Setting .....	21
Figure 1-21: Setting Clock Format and Displaying Date .....	22
Figure 1-22: Enable Display of Main Clock .....	23
Figure 1-23: Enabling/Disabling Alarms .....	24
Figure 1-24: Viewing Alarms .....	25
Figure 1-25: Edit Alarms Function .....	26
Figure 1-26: Selecting Active or All Parameters .....	27
Figure 1-27: Selecting Alarm Quantity .....	27
Figure 1-28: CAN Parameter Alarm Configuration Screen Detail .....	28
Figure 1-29: Alarm Configuration .....	29
Figure 1-30: Adding Additional Alarm(s) .....	30
Figure 1-31: Deleting Alarm(s) .....	31
Figure 1-32: Connector Analog Input Pins .....	32
Figure 1-33: A/D Input Setup .....	33
Figure 1-34: A/D Pressure Sender Input Configuration .....	34
Figure 1-35: Display Menu .....	35
Figure 1-36: Quick View Main Screen Parameter Selection .....	36
Figure 1-37: Adding Trim Parameters to Quick View Main Screen Display List ....	37
Figure 1-38: Trim Screen Formats .....	37
Figure 1-39: Adding Clock Display to Quick View Main Screen List .....	38
Figure 1-40: Quick View Main Screen Scrolling Style .....	38
Figure 1-41: Setting Quick View Main Screen Scrolling Style .....	39
Figure 1-42: Setting Quick View Main Screen Recall .....	39
Figure 1-43: Setting Key Off Display Options .....	40
Figure 1-44: Setting LCD Background Color Scheme .....	41

List of Figures

Figure 1-45: Setting LCD Contrast ..... 42

Figure 1-46: Setting Speedometer Source ..... 43

Figure 1-47: Calibration Menu ..... 44

Figure 1-48: Selecting a Fuel Tank to Configure. .... 45

Figure 1-49: Selecting Fuel Tank Data Source ..... 46

Figure 1-50: Setting Fuel Tank Capacity. .... 47

Figure 1-51: Setting Empty Tank Calibration Point ..... 48

Figure 1-52: Setting Tank Calibration Points for 25-100% ..... 49

Figure 1-53: Resetting Fuel Tank Calibration Data Points ..... 50

Figure 1-54: Viewing Fuel Tank Calibration Step 1 ..... 50

Figure 1-55: Viewing Fuel Tank Calibration Steps 2 thru 5 ..... 51

Figure 1-56: Saving Fuel Tank Data & Calibration Steps ..... 52

Figure 1-57: Engine Trim Calibration Menu ..... 53

Figure 1-58: Engine Trim Calibration Menu ..... 54

Figure 1-59: Setting Full-Down Trim Position ..... 55

Figure 1-60: Setting Full Up Trim Position ..... 56

Figure 1-61: Viewing Engine Trim Settings ..... 56

Figure 1-62: Saving Engine Trim Settings ..... 57

Figure 1-63: Popup Fault, Warning & Alarm Screens ..... 58

Figure 1-64: Acknowledging Fault, Warning or Alarm Notification ..... 58

Figure 1-65: Popup Engine/Tab Trim Screen ..... 59

Figure 1-66: Popup Menu ..... 60

Figure 1-67: Setting Trim Popup State ..... 61

Figure 1-68: Setting Fault Popup State ..... 62

Figure 1-69: Setting Warning Popup State ..... 62

Figure 1-70: Setting Alarm Popup State ..... 63

Figure 1-71: Enable All Popup Functions ..... 63

Figure 1-72: Disable All Popup Functions ..... 64

Figure 1-73: Setting CAN Bus Protocol ..... 65

Figure 1-74: Engine Sync No Data Message ..... 66

Figure 1-75: Setting SAE J1939 Engine Number ..... 67

Figure 1-76: Setting SAE J1939 Default Quick View Main Screen 1 ..... 68

Figure 1-77: Setting Master Node Instrument Instance Number ..... 69

Figure 1-78: Setting NMEA 2000® Engine Number ..... 70

Figure 1-79: Setting NMEA 2000 Default Quick View Main Screen 1 ..... 71

## • About

NexSysLink® is the next generation instrumentation system from Beede that combines the best of analog and digital data display technologies.

NexSysLink® reads and displays vehicle performance data directly from CAN (Controller Area Network) equipped apparatus that support protocols such as SAE J1939, NMEA 2000®, SmartCraft®, or Indmar and supports a maximum of three analog sender inputs. The system consists of a master node instrument and optional complementary minor (slave) node instruments. This system eliminates the need for a translation “black box” between an ECM/ECU and the instruments themselves making wiring and installation simple and fast.

## • Scope

This manual describes how to navigate the LCD interface and use the many features found in a NexSysLink® Master Node Instrument. Although the interface is intuitive and easy to navigate, this operation manual provides users with a resource to realize the full potential and capabilities of NexSysLink® instrumentation. Covered in this manual are display options, menu navigation and menu function usage.

Although some wiring connections are noted for easy reference, this manual does not cover complete installation mounting and wiring requirements. Please refer to the NexSysLink® installation instruction sheet for proper installation.

## • Preconfigured Instruments

Some instruments are preconfigured at the factory to individual OEM specifications to best meet the need of the application and end user. Preconfigured features include but may not be limited to the type and quantity of Quick View Main Screens, alarm configuration(s) and active CAN protocol. Preconfigured features are easily modified to satisfy personal preferences.

## • Menu Navigation

Menu navigation requires the use of three externally mounted momentary switches connected to the master node instrument. The switch functions are MENU/MODE/ENTER/RESET, UP and DOWN. These switches are supplied and installed by the vehicle/equipment manufacturer.

### • Menu/Mode/Enter/Reset Switch

As its name suggests, this switch serves several purposes when navigating the NexSysLink® user interface. The function depends upon the context of the menu.

**Menu Function:** Pressing and holding this switch for approximately three seconds while any of the Quick View Main Screens are displayed brings up the Main Menu.

**Mode Function:** Pressing and releasing this switch while any of the Quick View Main Screens are displayed toggles the display mode between three-line and detailed bar graph formats.

**Enter Function:** Pressing and releasing this switch provides enter functionality when NexSysLink® requires you to choose a menu item, parameter selection or value input.

**Reset Function:** Pressing and holding this switch resets trip miles and maintenance hour values to zero when either of those screens are displayed.

### • Up Switch

Pressing and releasing the Up switch scrolls up through parameter lists and menu choices or increases a value one item/unit at a time.

Pressing and holding the Up switch continuously scrolls up through parameter lists, menu choices or increases a value until the end of the parameter list, menu choices or maximum parameter value is reached.

### • Down Switch

The Down switch functions identical to the Up switch with the exception that its direction for all displays, menu choices and values is down or decreasing.

### • Switch Icon Conventions

Throughout this manual icons are used to indicate actions required by the user to navigate the menus. Below are descriptions and the corresponding action to be taken when they appear.



Press and release Menu/Mode/Enter/Reset switch icon.

The presence of this icon in the manual indicates when to press and release the Menu/Mode/Enter/Reset switch.



Press and hold Menu/Mode/Enter/Reset switch icon.

The presence of this icon in the manual indicates when to press and hold the Menu/Mode switch for approximately three seconds.



Press Up switch icon.

The presence of this icon in the manual indicates when to press and release the Up switch. Users may also choose to press and hold the Up switch if necessary.



Press Down switch icon.

The presence of this icon in the manual indicates when to press and release the Down switch. Users may also choose to press and hold the Down switch if necessary.

## • Menu Navigation (Continued)

NexSysLink® uses various icons and indicators to guide users for item selection and/or input while navigating the menus. The selection arrow and blinking bar cursors appear frequently throughout the menus.


### • Selection Arrow Cursor



The selection arrow cursor, shown at left, identifies adjacent menu items as the current selection. Pressing the Enter switch selects the menu item/function or value adjacent to the arrow cursor.

Pressing and releasing an Up or Down switch moves the selection arrow up or down a menu list one item at a time until the beginning or end of the list is reached. Pressing and holding the Up or Down switch continuously moves the selection arrow up and down a menu list until the switch is released or the beginning or end of the list is reached.

Figure 1-1: Menu Scrolling and Option Selection




• Blinking Bar Cursor

A blinking bar cursor appearing beneath a numeric value or parameter indicates the item may be changed by pressing or pressing and holding the Up or Down switches.

When a numeric value appears above a blinking bar cursor pressing or pressing and holding the Up or Down switch increases or decreases the value until the maximum value limits are reached.

When a parameter or parameter option appears above a blinking bar cursor pressing or pressing and holding the Up or Down switch scrolls through the list of parameters or parameter options until the end of the list is reached.

Figure 1-2: Blinking Bar Cursor



## • Start-up Screen

Upon Instrument start-up the Beede logo and/or one of several possible CAN based protocol logo(s) appear for approximately three seconds.

## • Default Quick View Main Screen

The default Quick View Main Screen appears after completion of the start-up routine and replaces the start-up logo. For marine applications, the first Quick View Main Screen display is factory set to show total hours and always appears as the first screen in the list of parameters/functions set for Quick View Main Screen display.

## • Quick View Main Screens

Quick View Main Screens allow for easy viewing of up to 12 commonly used vehicle operating parameters or functions by pressing the Up and Down switches. Users choose the quantity, order and type of parameters to include in the Quick View Main Screen list.


Quick View Main Screens are often factory configured to OEM requirements but are easily reconfigured to meet individual user preferences.

The first screen in the list of Quick View Main Screens is permanently set to total hours for marine applications. The total hours screen may not be removed from or reordered in the screen list.

The trim (engine and/or tab) screen along with the time/date screen always appears last in the screen display stack with trim appearing before time/date if both are enabled for display.

See "Display" on page 35 for configuring Quick View Main Screens.

Figure 1-3: Quick View Main Screens




• Bar Graph & Three Line Format

NexSysLink® can display vehicle operating parameters on the Quick View Main Screens in two formats, single parameter bar graph or three-line. The default display format is single parameter bar graph which provides the most detail for a given parameter. The three-line display allows users to view three parameters concurrently but with less detail. Total Hours, Total Miles and Engine Trim are not displayed in the three-line format.

Pressing and releasing the Mode switch while any Quick View Main Screen except Total Hours or Total Miles is active toggles between single parameter bar graph and three-line display formats.

When using the three-line format, if more than three parameters are configured for Quick View Main Screen display, use the Up and Down switches to scroll through the display stack. If fewer than three parameters are configured for viewing then less than three parameters appear with the three-line format active.

Figure 1-4: Setting Parameter View Display Format



## • Trips (Hours) Screen

NexSysLink® offers three maintenance hour logs or trips. To access the trips screen press and release the Enter switch when the total hours Quick View Main Screen is active. Pressing the Enter switch a second time returns the total hours screen.


The trips screen is also accessed by selecting *Main Menu - Trips*. See "Trips" on page 9.

## • Resetting Trips

To reset any of the three maintenance hour logs to zero, position the selection arrow cursor next to the trip hour log to be reset by using the Up or Down switch.

Once the selection arrow cursor is next to the log to reset, press and hold the Enter (Reset) switch until the value changes to zero.

Figure 1-5: Resetting Trip (Hour) Logs



• Main Menu


The Main Menu contains functions to configure the LCD (Liquid Crystal Display), set alarms or view ECM faults and warnings. Some frequently used Setup Menu functions are also located in the Main Menu to provide easier and faster access.

Access the Main Menu by pressing and holding the Menu switch while any Quick View Main Screen is active.

Like all NexSysLink® menus with multiple functions, only the first two Main Menu options appear on the screen below the menu name. Access the other options by scrolling down the menu list using the Down switch. Use the Up switch to scroll back up the Main Menu function list.

The Main Menu and all the functions within it except View Parameters will display for approximately 30 seconds if no user activity is detected. The first (Default) Quick View Main Screen appears after 30 seconds of inactivity.

Figure 1-6: Accessing the Main Menu




### • Trips

Selecting the trips function in the Main Menu displays three separate maintenance hour logs. This is an alternate method to pressing the Mode switch with any Quick View Main Screen active.

Resetting any of the three maintenance hour logs is described below and previously on page 7. The only difference from this method to the previously described method is the trips log is accessed using the Main Menu function Trips instead of pressing the Mode switch while a Quick View Main Screen is displayed.

Figure 1-7: Accessing Trip Logs from the Main Menu



### • View Parameters

View Parms is an abbreviation for viewing actively broadcast parameters and inputs. Parameter sources include analog inputs, NMEA 0183 input and CAN protocols. The quantity and type of parameters depends upon the CAN protocol used along with the configuration of analog inputs.


Parameters are displayed in single function bar graph format when viewed using View Parms. Use the Up and Down switches to scroll through the list of parameters. Analog input parameters display before CAN parameters. If the Master Node Instrument is configured with an NMEA 0183 input, the parameter will display last in the parameter viewing list. If the NMEA 0183 is available and not used, the display will indicate "Missing NMEA 0183 Data".

Unlike other Main Menu functions, the parameter display will not time-out after 30 seconds. Press the Mode switch to exit viewing parameters and display the first (Default) Quick View Main Screen.

Figure 1-8: Viewing Parameters



Select View Parms from the Main Menu, *Main Menu-View Parms*, then press the Enter switch to accept.



First actively broadcast parameter appears. Coolant temperature shown as an example only.

Use the Up and Down switches to scroll through the list of broadcast parameters. Parameter display will not time out.




Pressing the Mode switch returns the first Quick View Main Screen.

## • Setup

The Setup option in the Main Menu provides the functions necessary for configuring NexSysLink® to suit individual preferences or application requirements. Such functions range from backlight intensity to choosing and setting alarms. See page 18 for Setup Menu function descriptions.

Figure 1-9: Accessing the Setup Menu



• Mute

When a NexSysLink® Master Node Instrument is connected to a FWA (Fault, Warning & Alarm) Slave Node Instrument with audible output capabilities, the mute function temporarily turns off the audible alarm.

Faults are muted for 20 seconds. Warnings and alarms are muted for 2 minutes. Faults are muted for a shorter period of time because they are considered critical conditions that require immediate attention. A fault condition sounds a steady audible tone while warning and alarms sound an intermittent tone.


• Faults

Faults are an indicator of a severe vehicle problem as reported by the ECM/ECU that warrants stopping the engine/vehicle/vessel. Users should consult the owners manual or a service technician to correct the fault condition(s).

When a fault condition occurs, a blinking “F” icon appears at the bottom of the current Quick View Main Screen.

The *Main Menu-Faults* option allows users to view the parameter(s) causing the fault. If popups for fault conditions is enabled, a fault notification screen appears. Refer to “Set Popup” on page 58.

Figure 1-10: Fault Notification & Information Screens



• Warnings

Warnings are an indicator of vehicle problem as reported by the ECM/ECU that does not warrant immediately stopping the vehicle or vessel. Users should consult the owners manual or a service technician to correct the warning condition(s).

When a warning condition occurs a blinking “W” icon appears at the bottom of the current Quick View Main Screen.

Figure 1-11: Quick View Main Screen with Warning “W” Icon




The Main Menu Warnings option allows users to view the parameter(s) causing the warning. If popups for warning conditions is enabled, a warning notification screen appears. Refer to "Set Popup" on page 58.

Figure 1-12: Warning Notification and Information Screens

Warning List Screen  
Showing Two Active Warnings



Select Warnings option from the Main Menu to display active warnings.



To scroll up and down the warning list when more than three occur.

Fault Notification Screen  
Appears if Popups are Enabled.  
Refer to Setting Popups.



## • Alarms

Alarms are user configured limits for CAN or analog parameters used to alert operators when the parameter(s) exceeds those limits. Alarms help users protect a vehicle, vessel or equipment from damage by providing an option to set operating notification limits for parameters critical to the application.

The *Main Menu-Alarms* function allows users to view the parameter causing the alarm as well as provides all the functions necessary to configure alarms. The alarm function is also located in the Setup Menu. Refer to *Main Menu - Setup - Alarms* on page 24 detailed descriptions of all the Alarm Menu features.

Note: Alarms are only a notification feature and does not disable or diminish the operation of a vehicle or equipment.

NexSysLink® allows users to set up to 15 parameters for alarm notification.

Alarm settings are written to non-volatile memory and retained when power is removed from the instrument.

Once a parameter exceeds the set operating limits, a blinking “Bell” icon appears at the bottom of the current Quick View Main Screen.

Figure 1-13: Quick View Main Screen with Alarm “Bell” Icon




## • Recall

The recall function displays the maximum vehicle speed and engine RPM. The recall data is stored in non-volatile memory which retains the information until it is reset or overwritten by higher values.

To reset either recall value to zero, place the selection arrow cursor at the value to reset by using the Up and Down switches. Once the cursor is adjacent to the desired value, press and hold the Enter switch until the value changes to zero.

Figure 1-14: Recall Function



## • Fuel


The fuel Main Menu function provides fuel management data such as consumption rate, amount remaining and amount used.

In order to see and use all the fuel management features, fuel tanks must be calibrated using *Main Menu-Setup-Calibration* function found on page 44.

If the fuel tank(s) are not calibrated using the calibration setup routine, only the fuel rate option appears.

In order to display fuel rate data, Rate function, the engine/vehicle/vessel must be equipped with a fuel flow sensor.

Figure 1-15: Fuel Management Function



Fuel Menu functions summary:

Rate - Displays fuel consumption in GPH, gallons per hour. Requires fuel flow sensor.

Used - Displays amount of fuel consumed.

Added - Tells NexSysLink® fuel was added to the tank so fuel management is recalculated.


Return - Brings users back to Fuel option in Setup Menu.

Main Screen - Brings users back to the default Quick View Main Screen.

• Miscellaneous

The Miscellaneous Menu contains functions for restoring factory default settings, viewing current firmware revision and active CAN Bus protocol.

Figure 1-16: Miscellaneous Functions Menu



• Setup Menu

The Setup Menu contains all the functions necessary to configure a Master Node Instrument to satisfy user preferences and application requirements. This section of the manual describes those functions.

Figure 1-17: Setup Menu Functions



- Backlight
- Units
- Clock
- Alarms
- A/D Inputs
- Display
- Speedometer
- Calibration
- Set Popup
- Set CAN Bus
- Return
- Main Screen

To access the Setup Menu, *Main Menu-Setup*, press and hold the Menu Switch with any Quick View Main Screen displayed until the Main Menu appears.

Scroll to the Setup option using the Down Switch then press the Enter switch.

Setup Menu Function List (Standard)

Note: Since instruments are often factory configured to OEM specifications, some Setup Menu functions in the list may not appear.

Setup Menu functions summary:

- Backlight - Sets intensity of instrument illumination.
- Units - Sets display units to English or SI-Metric.
- Clock - For enabling/disabling clock display, setting time and clock display format.
- Alarms - For enabling/disabling, viewing and creating/editing parameter alarm notification.
- A/D Inputs - For configuring analog and NMEA inputs to a Master Node Instrument.
- Display - Use to add/delete Quick View Main Screens, set LCD key-off display, positive or negative image mode and adjust LCD contrast.
- Speedometer - Use to set speedometer type, CAN or GPS

• Backlight


Backlight intensity is set using the Backlight option from the Setup Menu.

Users can set backlight intensity for when the vehicle lamp switch is on (Lamp On option) or when the vehicle lamp switch is off (Lamp Off) option.

The lamp off option allows users to turn on the instrument(s) backlighting independent of the vehicles light switch.

Backlight intensity values range from 0 (off) to 100 (Max) by increments of 10.


Figure 1-18: Setting Backlight Intensity



• Units

Users may choose between English and SI-Metric units for parameter display. Users may also select between statute and nautical mile for marine odometer units. If SI-Metric units is chosen, the statute and nautical mile units are displayed in kilometers.

Figure 1-19: Setting Units



• Clock Viewing & Setting


NexSysLink® offers a digital clock display screen. Users enable/disable clock display, set clock time/format and enable date display using the clock menu functions.

• Viewing & Setting

If clock display is enabled, it always appears as the last Quick View Main Screen. Refer to "Quick View Main Screens" on page 5.

Time formats include hours:minutes and hours:minutes:seconds.


Figure 1-20: Clock Viewing and Time/Date Setting



• Clock Format

The clock display format can appear as either Hours:Minutes or Hours:Minutes:Seconds. The date can be added to the clock display and appears as a second line below the time display in the format of MM/DD/YY.


Figure 1-21: Setting Clock Format and Displaying Date



• Main Clock

The Main Clock function adds the clock as one of the Quick View Main Screen. The clock always appears as the last screen in the Quick View Main Screen list.

Figure 1-22: Enable Display of Main Clock



• Alarms

See "Alarms" on page 14 for a description of the Alarm function. The *Setup-Alarm* function is identical to the *Main Menu-Alarm* function.


This section provides detailed descriptions of all the Alarm Menu functions

• Enabling Alarms

Alarm enable turns on or off notification when an alarm condition occurs. This function does not delete alarms or their settings from the alarm list.

To protect against operating the vehicle unaware of potentially damaging conditions, always use caution when deciding to turn off alarms.


Figure 1-23: Enabling/Disabling Alarms



• Viewing Alarms

View Alarms allows users to scroll through all parameters causing the alarm condition(s). The parameter(s) causing the alarm condition will have the actual measured value blinking. To exit alarm review and return to the Quick View Main Screen, press the Enter switch.


Figure 1-24: Viewing Alarms



• Editing Alarms

The edit alarm function is how users add, delete and configure limits of selected CAN parameters or configured analog inputs for alarm notification. If alarms were previously set, users should view and note the current alarm parameter type, order and settings before editing.

Figure 1-25: Edit Alarms Function



### • Active & All Parameters Selection Sets

When selecting parameters for alarm notification, users can choose from the actively broadcast parameters or all parameters defined by the CAN protocol.

The active CAN parameters selection set includes those parameters that are currently or “actively” broadcast on the CAN network and read by NexSysLink®. Active parameters also include any analog inputs configured using the A/D Input function. Active CAN parameters are, in most cases, a subset of the all CAN parameters set.

All CAN parameters or “All Parms” selection set contains all parameters defined by a specific CAN protocol standard whether or not it is currently broadcast on the CAN network and all analog inputs NexSysLink® is capable of reading.

Figure 1-26: Selecting Active or All Parameters

Edit Alarms Menu  
Showing  
Active/All Parms  
Selection Options



Place the selection arrow cursor next to the desired option and press the Enter switch to begin selecting parameters for alarm notification.

Active selection set includes all currently broadcast parameters and analog inputs.

All Parms selection set includes all parameters defined by the CAN protocol and analog inputs.

It is not recommended to select parameters from the “All Parms” list since the parameter may never broadcast over the CAN network and, as a result, trigger an alarm notification. Users that select parameters from the “All Parms” list should do so knowing the parameter(s) will be broadcast on the CAN network to which NexSysLink® instruments are connected.

### • Setting Quantity of Alarms

Users can set a maximum of 15 alarms. Simply increase or decrease the alarms value in the Select Alarms screen with the Up or Down switch. Pressing the Enter switch accepts the displayed value.

Figure 1-27: Selecting Alarm Quantity

Select Alarm  
Quantity Screen



Blinking bar cursor appears under select alarm quantity value. Use Up and Down switches to set desired value then press Enter switch to accept.

When no alarms are set, the alarm quantity will appear as zero (0).

If alarms are set, the alarm quantity will indicate the current number of set alarms.

Regardless of the quantity displayed, increasing the value adds a new or additional alarm to the alarm list and decreasing the value removes alarms from the list.

Changing the alarm quantity to zero (0) deletes all set alarms.

• Alarm Configuration

After setting the alarm quantity, the alarm configuration screen appears with the blinking bar cursor below the first available parameter to include as an alarm parameter.

When configuring an alarm, users must tell NexSysLink the following:

- 1. The parameter to use.
- 2. The trigger threshold direction (Higher or Lower than alarm trigger value).
- 3. The alarm trigger value.

Analog Parameter Alarm Configuration Screen Detail




Figure 1-28: CAN Parameter Alarm Configuration Screen Detail



Parameters for selection and inclusion in the alarm list appear in random order. However, all analog input parameters appear before CAN parameters. Scroll through the parameter list with the Up and Down switches until the desired parameter appears. Press the Enter switch to add the parameter to the alarm list.


After selecting a parameter, the blinking bar cursor appears under the Higher/Lower than arrow icon. Users must choose if the alarm notification will occur when the actual parameter value is either higher or lower than the desired trigger value. Pressing either the Up or Down switch toggles the indicator between the higher than arrow (pointing up) and lower than arrow (pointing down). Press the Enter switch to accept direction of the arrow icon.

Once higher or lower is chosen, the blinking bar cursor moves to the alarm notification or trigger value. The units of this value change depending on the type of parameter chosen. Use the Up or Down switches to change the value then press Enter switch to accept the displayed value.

If only one alarm was entered in the Select Alarms Screen, the Edit Alarms Menu reappears after setting the first alarm. If two or more alarms were entered in the Set Alarms Screen, the alarm configuration screen reappears with the blinking bar cursor beneath the parameter name awaiting selection of the next parameter to add to the alarm list. Repeat the process to add subsequent alarms if required.

Figure 1-29: Alarm Configuration

Alarm #1  
Configuration Screen



Navigate to the Edit Alarms screen, *Main Menu-Alarms-Edit* or *Main Menu-Setup-Alarms-Edit*, select a parameter list and alarm quantity to bring up Alarm #1 configuration screen.

The blinking bar cursor appears under a parameter name. Use the Up and Down switches to scroll to desired parameter then press the Enter switch to accept.

Higher/Lower  
Option Screen



After selecting a parameter, the blinking bar cursor appears under the higher/lower than indicator.

Press either the Up or Down switch to toggle arrow direction then press Enter switch to accept direction.

Alarm Value  
Setting Screen



After setting higher/lower indicator, the blinking bar cursor appears under alarm indication value.

Use the Up and Down switches to set value then press Enter switch to accept.

Alarm #2  
Configuration Screen



Alarm #2 configuration screen appears when setting more than one alarm.

Repeat the process above to configure the alarm and all other alarms when required.

Alarms Menu



Pressing Enter switch when only one or the last alarm is set returns the Alarm Menu with the selection arrow cursor next to the Edit option.

• Adding Additional Alarms

Repeat the edit alarm process to add additional alarms. When prompted for the alarm quantity, increase it by the desired number of additional alarms. Once the alarm quantity increase is accepted, the first of all previously configured alarms appear.

Bringing up previously configured alarms gives users the opportunity to review, edit or completely change the current alarm parameters and configurations. If no changes are desired for previously configured alarms, users simply “step through” them by pressing the Enter switch to accept existing settings. If many alarms were set prior to adding additional alarms, users will need to press the Enter switch many times to leave current alarms unchanged before adding the new parameter to the alarm list.

The new alarm parameter is added to the end of the existing alarm list.

Figure 1-30: Adding Additional Alarm(s)




Navigate to the Select Alarms Quantity screen, *Main Menu-Alarms-Edit-Active or All Params.*

Two previously set alarms shown as an example.



Press the Up switch to increase the alarm quantity by the desired amount.

This example increases the alarm quantity to three. Press the Enter switch to accept the quantity shown.



Alarm #1 screen, the first of all the previously configured alarms, appears with the blinking bar cursor beneath the parameter name.

Users may change the settings for any previously configured alarms, two in this example, or “step through” them to accept current settings using the Enter switch.

The new alarm, Alarm #3 screen, appears once “stepping through” or editing of all previous alarms is complete. Select the parameter and settings for the new alarm.

### • Deleting an Alarm

Repeat the edit alarm process to delete an alarm. When prompted for the alarm quantity, decrease it by the number of alarms to be removed. NexSysLink® uses a last in first out (LIFO) algorithm. Therefore, decreasing the alarm quantity deletes the last alarm entered. If users wish to delete the first alarm, all alarms must be deleted and the alarms to be retained must be re-entered using the edit alarm function.

Figure 1-31: Deleting Alarm(s)



### • A/D (Analog/Digital) Inputs

Analog sender or A/D inputs are used to connect discrete non-CAN senders such as fuel level, engine trim and water pressure. NexSysLink® reads the analog signal and converts it to a digital signal for processing.

Depending upon the NexSysLink® Master Node Instrument version, users may connect up to three analog senders.

Configuring A/D inputs “tells” a NexSysLink® Master Node Instrument the type of sender used and to what analog input pin the sender is connected. Users must know this combination before configuring A/D inputs. It does not matter which analog input pin is used as long as the A/D input is configured to match the physical hardware connections.

Example: If a 240-33 ohm fuel sender is wired to pin 7 (analog input 1) then users should set analog input 1 to a Fuel Level parameter with a resistance range of 240-33 ohms.




Figure 1-32: Connector Analog Input Pins


See the following page for A/D input setup display screens.

### • NMEA 0183 Input

If factory configured, analog input 2 can read NMEA 0183 data from compliant devices such as GPS receivers and smart transducers.

If analog input 2 is factory configured for NMEA 0183, the only parameter options for the input are None and NMEA 0183.

Figure 1-33: A/D Input Setup




#### • A/D Pressure Sender Inputs

Configuring an analog pressure sender input differs slightly from other analog inputs. With pressure senders, users must tell NexSysLink® the pressure range for the sender by inputting the pressure at 0% and 100% of full scale. This is in addition to setting the sender resistance range.

See the following diagram for configuring an analog pressure sender.


Figure 1-34: A/D Pressure Sender Input Configuration



• Display

The Display Menu functions give users the ability to configure the LCD. Options for configuring the display include brightness, contrast, viewing mode and which parameters to include in the Quick View Main Screen stack. Each function is detailed in the following pages.

Figure 1-35: Display Menu




• Main Order

The Main Order function is used to select the quantity of parameters and order in which they will display when scrolling through the Quick View Main Screens.

See following page for detailed instructions.

Figure 1-36: Quick View Main Screen Parameter Selection




• Main Trim

Because trim is a commonly used function for NMEA 2000® configured CAN instruments, the Main Trim function provides a fast way to display engine trim and trim tab position to the Quick View Main Screens. If a vessel is equipped with engine trim and trim tabs, Main Trim consolidates all three functions on one screen. This function only works with CAN trim parameters.

When added to the screen display list in this method, the trim screen will appear last in the Quick View Screen List or second to last if Main Clock is enabled for display.

Figure 1-37: Adding Trim Parameters to Quick View Main Screen Display List




• Trim Screen Formats

Depending on the number of trim devices, the Main Trim Quick View Screen may display from one to three trim position indicators as shown in the figure below.

“E” bar graph indicates engine or outdrive trim while the “P” and “S” bar graphs indicate port and starboard trim tabs respectively.

Figure 1-38: Trim Screen Formats



• Main Clock

Main Clock function adds a clock display to the Quick View Main Screens. The clock can also be added or removed from the Quick View Main Screens by using *Main Menu-Setup-Clock-Main Clock-On or Off*. The clock always appears as the last Quick View Main Screen and may not be reordered in the screen list.

Figure 1-39: Adding Clock Display to Quick View Main Screen List



Select Main Clock from the Display Menu, *Main Menu-Setup-Display-Main Clock*. The On option adds clock display to the Quick View Main Screens while off removes it. Place the selection arrow cursor next to the desired option then press the Enter switch to accept.

• Main Roll

Main Roll sets the style of scrolling through the Quick View Main Screens. With Main Roll set to Roll, pressing the Up and Down switches continuously loops through the Quick View Main Screens such that when the last screen is reached pressing the Down switch displays the first screen. With Main Roll set to No Roll, scrolling stops at the first or last Quick View Main Screen. This setting requires users to press the Up switch to scroll back up the through when the last screen is reached or press the Down switch when the first screen is displayed.

Figure 1-40: Quick View Main Screen Scrolling Style





Figure 1-41: Setting Quick View Main Screen Scrolling Style



Select Main Roll from the Display Menu,  
Main Menu-Setup-Display-Main Roll.  
Press the Enter switch to accept.



The Main Roll Menu appears.  
The Roll option enables continuous  
scrolling/looping of Quick View Main Screens.  
No Roll stops screen scrolling when the top or  
bottom of the screen list is reached.  
Place the selection arrow cursor next to the  
desired option then press the Enter switch to accept.

#### • Main Recall

Recall enables NexSysLink® to remember the last Quick View Main Screen displayed when the ignition key is turned off so that screen will appear when the key is turned back on. This features eliminates the need to scroll through the Quick View Main Screens to display a preferred parameter every time the vehicle is turned off. The No Recall option returns the default Quick View Main Screen (Total Hours) when the ignition key is turned off and then back on regardless of the last screen displayed.

Figure 1-42: Setting Quick View Main Screen Recall



Select Main Recall from the Display Menu,  
Main Menu-Setup-Display-Main Recall,  
Press the Enter switch to accept.



The Recall option remembers the last Quick View  
Main Screen displayed when the ignition key  
is turned off so that screen will appear when  
the key is turned back on.

No Recall ignores the last Quick View Main Screen  
displayed when the ignition key is turned off.

Place selection arrow cursor next to the desired  
option then press the Enter switch to accept.

1. As a general rule, horizontal lines within the flow chart represent pressing the Enter switch while vertical lines represent pressing the Up or Down switch.

2. The initial quantity and type of Quick View Main Screens configured for display is factory set to OEM specifications.

3. Pressing and holding the Enter switch for approximately three seconds with any screen displayed returns users to the Main Menu.

4. Several menu items are contextual and require user input to access all menu options.

• Key Off


Users can choose to retain the clock or ODO/Hours displays when the ignition key is turned off.

Note: This feature turns on the LCD and not the LCD backlight. The transfective nature of the LCD will allow for viewing in low ambient lighting conditions. For optimum viewing, turn the ignition key on to enable the LCD backlight. Refer to "Backlight" on page 18 for instrument illumination setup.

Figure 1-43: Setting Key Off Display Options



Select the Key Off option from the Display Menu, *Main Menu-Setup-Display-Key Off*. Press the Enter Switch to accept.



When the ignition key is turned off, the No Display option blanks or turns off the LCD.

The Clock option retains a clock display while Odo/Hours retains either the total hours or total miles display when the ignition key is turned off.

Place the selection arrow cursor next to the desired option then press the Enter switch to accept.



Pressing the Down switch scrolls to the remainder of the Key Off Menu options.

• Set Video

Setting video changes the color scheme of the LCD from white graphics on a black background (Normal) to black graphics on a white background (Reverse).


Figure 1-44: Setting LCD Background Color Scheme



Select Set Video from the Display Menu, Main Menu-Setup-Display-Set Video. Press the Enter switch to accept.



From the Video Mode Menu, users can choose Normal (white text on black background) or Reverse (Black text on white background). Place the selection arrow cursor next to the desired option then press the Enter switch to accept.



Video Mode  
Function List



Set Video = Normal



Set Video = Reverse

• Set Contrast

Contrast sets the difference between the white and black colors of the LCD.

Figure 1-45: Setting LCD Contrast



Select Set Contrast from the Display Menu, *Main Menu-Setup-Display-Set Contrast*. Press the Enter switch to accept.



Use the Up and Down switches to increase or decrease contrast. Press the Enter switch to accept contrast setting.

## • Speedometer

NexSysLink® reads both CAN and GPS based speed inputs. This function tells NexSysLink® what speed source to use to drive the speedometer pointer in a Master or Slave Node Instrument. Should more than one speed source exist, users can view all speed data on the LCD by selecting View Params from the Main Menu. It is not necessary to set the speedometer source if the vehicles instrument set does not contain speedometer.


### • CAN Speedometer

The CAN speed drives the pointer in the Master or Slave Node Instrument from a CAN source. CAN speed sources are further defined by either a water or ground based speed references.


### • GPS (NMEA 0183) Speedometer

The GPS option drives the pointer in the Master or Slave Node Instrument from NMEA 0183 compliant GPS speed sources. A NexSysLink® Master Node Instrument must be factory configured with analog input 2 (Pin 8 of the twelve pin connector) dedicated to read NMEA 0183 sources. If analog input 2 is NMEA 0183 configured, users must set A/D (Analog/Digital) input 2 to NMEA 0183 using *Main Menu-Setup-A/D Inputs* prior to setting the speedometer source to GPS. Refer to page 32, setting A/D inputs.

Figure 1-46: Setting Speedometer Source



Select Speedometer from the Display Menu, *Main Menu-Setup-Display-Speedometer*. Press the Enter switch to accept.



The Speedometer Menu appears, select CAN Bus or GPS (NMEA 0183) speed source.



CAN Speed Menu appears if CAN Bus is selected in the Speedometer Menu.

CAN speed source selection must be refined to water or ground references.


Select the appropriate option then press the Enter switch to accept.

• Calibration- Fuel Tank

The calibration function helps insure accuracy of fuel and engine trim parameters.

Calibration is a multi-step process requiring users to input characteristics of the tank or engine trim positions. Up to two fuel tanks can be calibrated. The process for calibrating tank 1 or tank 2 is identical.

Figure 1-47: Calibration Menu



Calibration menu functions summary:


- Tank 1 - Configures and calibrates fuel tank 1
- Tank 2 - Configures and calibrates fuel tank 2 if necessary.
- Tank Display - Sets display format of fuel remaining as a volume or percent of full when selecting Main Menu-Fuel-Remaining.
- Engine Trim - Configures and calibrates engine trim position.
- Return - Brings users back to calibration option on Display Menu.
- Main Screen - Brings users back to the default Quick View Main Screen.

• Calibration Tank 1 or 2

The process calibrating a fuel tank requires entering a source for the fuel data, setting fuel tank capacity and calibrating the fuel tank level. The next several pages detail each step of the process. Calibrate, Reset and View Steps Menu options do not appear until source and capacity information is entered.

Note: Original equipment manufacturers may precalibrate tank/sender combinations.

Figure 1-48: Selecting a Fuel Tank to Configure.



### • Setting Fuel Tank Data Source

After deciding which tank to calibrate, users must choose a source for the fuel data.

The source can be a CAN parameter, A/D input (analog discrete fuel sender) or None. Selecting the None option still provides fuel level information but disables fuel management data for the tank.

If A/D input is chosen, users must first configure an analog input using the A/D Inputs setup function. Refer to "A/D (Analog/Digital) Inputs" on page 32 for configuring fuel as an A/D input.

Figure 1-49: Selecting Fuel Tank Data Source



Select source from the Tank 1 Menu,  
*Main Menu-Setup-Display-Calibration-Tank 1*.  
Press the Enter switch to accept.



Pressing the Enter switch brings up the  
first fuel tank data source of "NONE".  
This option still provides fuel level information but  
disables fuel management data for the tank.



Pressing the Down switch scrolls to the  
next fuel tank data source "A/D Fuel 1",  
This option tells NexSysLink to use an  
analog input configured sender as a fuel  
level data source.  
Refer to the section on configuring A/D Inputs,  
*Main Menu-Setup-A/D Inputs*.




Pressing the Down switch again scrolls to the  
third and final fuel tank source option,  
CAN Fuel 1.  
This option tells NexSysLink to use CAN data  
as a fuel level data source.

### • Setting Fuel Tank Total Capacity

Setting tank capacity is the second step in the calibration process. It is important to enter an accurate capacity amount for the fuel tank since accurate fuel sender calibration relies on this information.

Figure 1-50: Setting Fuel Tank Capacity.



### • Calibrating Fuel Tank Level

The final step for calibrating fuel level indication requires characterizing the sender to the actual fuel tank level. Manually characterizing a fuel sender to the fuel tank accounts for possible fuel level errors due to complex shaped tanks and fuel sender mounting location.

A properly calibrated fuel take is necessary to calculate accurate fuel consumption rates.

Calibrating the fuel tank level requires starting with an empty fuel tank and then filling the tank with fuel in intervals or “steps” of 25%, 50%, 75% and 100% of tank capacity by volume. At each step NexSysLink® displays the current percentage of the senders full-scale range and the amount of fuel to be put in the tank. When the required amount of fuel for a calibration step is placed in the tank, pressing the Enter switch sets the current sender resistance to that amount of fuel in the tank.

Example: Calibrating an 80 gallon fuel tank requires users to set the sender resistance when the tank is empty and after placing 20, 40, 60 and 80 gallons of fuel in the tank. The following figures show each step in the process of calibrating a sample 80 gallon tank.

### • Calibrating Fuel Tank Level Step 1 - Empty Tank

Figure 1-51: Setting Empty Tank Calibration Point



Select **Calibrate** from the Tank 1 Menu,  
*Main Menu-Setup-Calibration-Tank 1-Calibrate.*  
Press the Enter switch to begin tank level calibration.



The first calibration point appears for empty tank.

The percent value shown represents the amount of fuel currently in the tank as a percentage of the senders full-scale range.

At empty, this percentage may indicate the tank is not actually empty, an improperly adjusted float arm or simply within the tolerance of the sender.


Make adjustments to the fuel level or sender otherwise press the Enter switch to move to the second calibration point.

### • Calibrating Fuel Tank Level Steps 2 thru 5

Setting the remaining calibration points for 25-100% of tank capacity is identical to setting the empty tank calibration point except for the required amount of fuel at each calibration point. The amount of fuel needed in the tank is displayed on the LCD and is based upon the total tank capacity set earlier.

The diagram below continues the process of calibrating the sample 80 gallon fuel tank. The percentages shown are used as an example only and will vary depending upon the sender characteristics.

Figure 1-52: Setting Tank Calibration Points for 25-100%




It is recommended users save calibration settings after completing step 5. See "Saving Fuel Tank Calibration Data" on page 52.

• Resetting Fuel Tank Calibration

The calibration points for a fuel tank can be reset by using the reset option found in either the Tank 1 or Tank 2 menus. This option only appears if calibration data was entered for a tank.


Figure 1-53: Resetting Fuel Tank Calibration Data Points



• Viewing Calibration Steps

Users can view/review all five calibration steps and the percent of full-scale sender range for those steps.

Figure 1-54: Viewing Fuel Tank Calibration Step 1




• Viewing Calibration Steps 2 thru 5

Pressing the Down switch after the first calibration step is displayed scrolls through the remaining calibration steps 2 thru 5.

The values shown in the figure below are from the 80 gallon tank example shown earlier. Values shown will vary for each user.

Figure 1-55: Viewing Fuel Tank Calibration Steps 2 thru 5



• Saving Fuel Tank Calibration Data

After making fuel tank source, capacity or calibration changes, users must save the changes for NexSysLink® to retain the information.

Figure 1-56: Saving Fuel Tank Data & Calibration Steps



Select Save from the Tank 1 Menu, Main Menu-Setup-Calibration-Tank 1-Save. Press the Enter switch to open Save Tank 1 Menu.




The selection arrow cursor appears at the “No” option to prevent accidental replacement of existing data. Move the selection arrow cursor next to the “Yes” option using the Up switch then press the Enter switch to save the calibration data.

• Tank Display

Users may select to view fuel remaining as either a volume or percent of full with the Tank Display function. This setting does not effect the fuel consumption rate display unit which remains volume per unit time such as gallons per hour (GPH).



Select Tank Display from the Calibration Menu, Main Menu-Setup-Calibration-Tank Display.




The Display Tank Menu appears with the selection arrow cursor next to the volume option. Select Volume or Percent then press the Enter switch to accept.

### • Calibration - Engine Trim

The implementation and accuracy of trim senders may vary greatly on a vessel. The engine trim calibration feature allows users to characterize the engine trim position to better match the sender, satisfy personal preferences or set a safety margin to the full-up or down positions.

Engine trim calibration is a three-step process requiring users to input trim source along with full-up and full-down calibration points.

Figure 1-57: Engine Trim Calibration Menu



Engine Trim Calibration Menu function summary:

Source - Provides options for analog, CAN Bus or No calibration (None) trim data sources.

Full Down - Sets calibration point for full-down engine trim position.

Full Up - Sets calibration point for full-up engine trim positions.

View - Shows previously set engine trim calibration points.

Save - Saves any changes to engine trim calibration options.

Return - Brings users back to the engine trim option, *Main Menu-Setup-Calibration-Engine Trim*.

### • Selecting Engine Trim Sender Type for Calibration

Users may choose to calibrate either analog or CAN Bus trim sender types. A "No Cal" option permits the use of OEM sender calibration or setup. Trim senders are still read by NexSysLink® when No Cal is chosen but this may result in the physical full-up or down engine trim positions not matching the full scale display on the Master Node LCD or pointer position of a Slave Node trim gauge connected to the Master Node Instrument.

Whether or not a trim sender is calibrated, analog trim senders must first be configured as an analog input using the A/D Inputs setup function in order to read the analog trim sender. Refer to "A/D (Analog/Digital) Inputs" on page 32 for configuring trim as an A/D input. CAN Bus trim senders are automatically read by NexSysLink®.

Figure 1-58: Engine Trim Calibration Menu



Select Engine Trim from the Calibration Menu, *Main Menu-Setup-Calibration-Engine Trim*. The selection arrow cursor appears next to the source option.

Press the Enter switch to select a trim sender signal source for calibration.



The Engine Trim Menu appears with the selection arrow cursor next to the No Cal option. Select this option to use the OEM calibration or sender setup.

Move the selection arrow cursor next to Analog then press the Enter switch to select an analog type trim sender for calibration.



Scroll down farther to place the selection arrow cursor next to the CAN Bus option then press the Enter switch to select a CAN compatible trim sender for calibration.

### • Calibrating Full-Down & Full-Up Trim Sender Positions

Once a trim sender source is selected, the options for calibrating the full-down and up trim positions appear. Setting full-down and up positions allows users to maximize the full trim sender range or set an offset for either or both the up or down positions.

As an example, setting the full-up position at 80% of the full sender range creates an offset. This type of offset could be used to identify the ideal trim position for operation yet leaves room for trimming the engine higher for trailering.

Figure 1-59: Setting Full-Down Trim Position




After selecting a trim sender source, select Full Down from the Engine Trim Menu, *Main Menu-Setup-Calibration-Engine Trim-Full Down*. Press the Enter switch to begin setting full-down position.



The engine trim Full Down Menu appears with the selection arrow cursor next to the No Change option.

Move the selection arrow cursor to the Set option and trim the engine to the desired down position.

As the engine is trimmed, the percent of full-scale trim value changes. If an offset for the down position is desired, trim the engine to a percent value greater than zero otherwise trim to 0%.



Once the desired percent value is reached, press the Enter switch to set the calibration point.

After setting the full-down position and pressing the Enter switch, the Engine Trim Menu appears with the selection arrow cursor next to the Full Down option.

Figure 1-60: Setting Full Up Trim Position



Place the selection arrow cursor next to the Full Up option in the Engine Trim Menu, *Main Menu-Setup-Calibration-Engine Trim-Full Up*. Press the Enter switch to begin setting full-up position.



The engine trim Full Up Menu appears with the selection arrow cursor at the No Change option.

Move the selection arrow cursor to the Set option and trim the engine to the desired up position.


As the engine is trimmed, the percent of full-scale trim value changes. If an offset for the up position is desired, trim the engine to a percent value less than 100% otherwise trim to 100%.

Once the desired percent value is reached, press the Enter switch to set the calibration point.

• Viewing Trim Calibration Settings

The view option provides an easy method to simultaneously review the trim settings for both up and down positions.

Figure 1-61: Viewing Engine Trim Settings



Place the selection arrow cursor next to the View option in the Engine Trim Menu, *Main Menu-Setup-Calibration-Engine Trim-View*. Press the Enter switch to view trim calibration settings.




The View E Trim screen displays the calibration settings for both the up and down positions.

### • Saving Trim Calibration Settings

To retain any changes to engine trim source or calibration settings, users must save them before exiting the Engine Trim Menu.

Figure 1-62: Saving Engine Trim Settings



Place the selection arrow cursor next to the Save option in the Engine Trim Menu, *Main Menu-Setup-Calibration-Engine Trim-Save*. Press the Enter switch to open Save E Trim Menu.



If changes were made to either the source or calibration points, the Yes/No save options appear.

The selection arrow cursor appears next to the No option to protect against accidentally replacing existing settings.

Move the selection arrow cursor to the Yes option then press the Enter switch to save changes or settings.

Or



If no changes were made to either the source or calibration points, the Save E Trim Menu appears displaying No Change.

Press the Enter switch to return to the Engine Trim Menu.

• Set Popup

Turning on popups provide a highly visible alert screen when a system fault, warning or alarm occurs.

Figure 1-63: Popup Fault, Warning & Alarm Screens




When popups are enabled, the following screens appear if a fault, warning or alarm occurs.

Fault, warning and alarm popup screens remain displayed until acknowledged by pressing either the Enter, Up or Down switches. Pressing the Enter switch returns the screen that was active when the fault, warning or alarm condition occurred but a blinking icon appears at the bottom of the screen to indicate a fault, warning or alarm condition exists. Pressing the Up or Down switch brings up the detail screen for the alarm condition.

Note: If the condition that caused the fault, warning or alarm clears, the notification screens and icons will disappear as well.

Figure 1-64: Acknowledging Fault, Warning or Alarm Notification




Pressing the Enter switch returns the screen displayed prior to the fault, warning or alarm with a blinking icon appropriate to the condition.  
(Total hours shown as an Example)

Pressing the Up or Down switches displays a screen with details about the fault, warning or alarm.  
(Check engine shown as an Example)

• Trim Popup Function

Since engine trim and trim tab positions are frequently adjusted, enabling the popup feature for trim temporarily brings up the appropriate trim detail screen when a change in trim position occurs. This feature allows users to see the trim position screen yet have the prior screen reappear several seconds after trim adjustments are completed.

Figure 1-65: Popup Engine/Tab Trim Screen



• Popup Menu

The Popup Menu is found in the setup section of the Main Menu and provides all the options for enabling/disabling popup screens. Users can turn on popups for each feature individually or use the Enable/Disable All function to turn on popups for all features in one step.

Figure 1-66: Popup Menu



Select Set Popup from the Setup Menu, Main Menu-Setup-Set Popup. Press the Enter switch to accept.



Set Popup Menu appears with the selection arrow cursor next to the Trim option. Move selection arrow cursor to desired Set Popup option then press the Enter switch to set popup state.



Set Popup Menu function list. The Enable All and Disable All options will not appear if all popups are already set to on or off respectively.

• Enabling/Disabling Popup Features

Enabling or disabling the popup feature for trim, fault, warning and alarm functions requires navigating to the Set Popup Menu found within the Setup Menu and selecting which function to set. Simply choose yes or no to enable or disable the popup for each function.

To enable or disable the popup feature for all four functions simultaneously, the Enable All or Disable All menu option provides this functionality.

Refer to the next several diagrams for setting the popup state for the various functions.

Figure 1-67: Setting Trim Popup State



Select Set Popup from the Setup Menu, Main Menu-Setup-Set Popup. Press the Enter switch to accept.



Set Popup Menu appears with the selection arrow cursor next to the trim option. Press the Enter switch to set trim popup state.



Popup Trim Menu appears. Selection arrow cursor location depends upon current state of trim popup.


If trim popup is on, the arrow will appear next to "Yes" option and if off next to "No" option.

Select "Yes" to turn on trim popup and "No" to turn off trim popup.

Figure 1-68: Setting Fault Popup State



Select Fault option from the Set Popup Menu, *Main Menu-Setup-Set Popup-Fault*. Press the Enter switch to set fault popup state.



Popup Fault Menu appears. Selection arrow cursor location depends upon current state of fault popup.

If fault popup is on, the arrow will appear next to "Yes" option and if off next to "No" option.

Select "Yes" to turn on fault popup and "No" to turn off fault popup.

Figure 1-69: Setting Warning Popup State



Select Warn option from the Set Popup Menu, *Main Menu-Setup-Set Popup-Warn*. Press the Enter switch to set warning popup state.



Popup Warn Menu appears. Selection arrow cursor location depends upon current state of warning popup.

If warning popup is on, the arrow will appear next to "Yes" option and if off next to "No" option.

Select "Yes" to turn on warning popup and "No" to turn off warning popup.

Figure 1-70: Setting Alarm Popup State



Select Alarm option from the Set Popup Menu, *Main Menu-Setup-Set Popup-Alarm*. Press the Enter switch to set warning popup state.



Popup Alarm Menu appears. Selection arrow cursor location depends upon current state of alarm popup.

If alarm popup is on, the arrow will appear next to "Yes" option and if off next to "No" option.

Select "Yes" to turn on alarm popup and "No" to turn off alarm popup.

Figure 1-71: Enable All Popup Functions




If available, select Enable All option from the Set Popup Menu, *Main Menu-Setup-Set Popup-Enable All*. Press the Enter switch to enable popup state for all functions.



The All Popup Active screen appears after selecting Enable All.

Figure 1-72: Disable All Popup Functions



If available, select Disable All option from the Set Popup Menu, *Main Menu-Setup-Set Popup-Disable All*. Press the Enter switch to enable popup state for all functions.

The All Popup Inactive screen appears after selecting disable all.

## • Set CAN Bus

NexSysLink® Master Node Instruments are often configured with several CAN protocols from which users can select. The Set CAN Bus function allows users to change to a desired protocol.

Note: Use the *Main Menu-Miscellaneous-CAN Bus* function to view the currently set protocol.

Set CAN Bus Menu allows users to set the engine number to which a Master Node Instrument is connected in multiple engine applications. See "Setting SAE J1939 Engine Number" on page 67 and also "Setting NMEA 2000® Engine Number" on page 70.

The Set CAN Bus Menu is also used to set the Default Quick View Main Screen 1 to display either total miles or total hours. See "Setting SAE J1939 Default Quick View Main Screen 1 (Total Hours or Miles)" on page 68 and also "Setting NMEA 2000® Default Quick View Main Screen 1 (Total Hours or Miles)" on page 71

Figure 1-73: Setting CAN Bus Protocol



Set CAN Bus Menu function summary:

SAE J1939 - Sets CAN protocol a Master Node Instrument reads to SAE J1939.  
 Indmar - Sets CAN protocol a Master Node Instrument reads to Indmar engines.  
 NMEA 2000 - Sets CAN protocol a Master Node Instrument reads to NMEA 2000®.  
 Save - Saves the engine CAN protocol setting.  
 Return - Brings users back to the Set CAN Bus Setup Menu option.  
 Main Screen - Brings users back to the default Quick View Main Screen.

### • Multiple Engine Applications

Multiple engine applications require a Master Node Instrument for each engine. Each engine has a unique CAN identification "engine number". The "engine number" is set by the either the engine manufacturer or the OEM that implements the engine. NexSysLink® supports up to four engines per vehicle or vessel.

In order to read CAN data from an engine in multiple engine configurations, each NexSysLink® Master Node Instrument must be "told" the engines number from which it will read CAN data and be wired to that engines ignition key switch.

If either requirement is incorrect, the Master Node Instrument will not power up or read data from the engine when the engines ignition key is turned on.

When wired properly, determining if a Master Node Instrument is synced to the proper engine number simply requires turning on the ignition key switch and waiting to see if engine hours accumulate.

If engine hours do not accumulate or the message "No Data" appears, use the *Main Menu-Setup-Set CAN Bus* tool to change the engine number of the Master Node Instrument until the Master Node reads CAN data from the desired engine.

For procedure on setting the engine number for SAE J1939, see "Setting SAE J1939 Engine Number" on page 67

For procedure on setting the engine number for NMEA 2000®, see "Setting SAE J1939 Default Quick View Main Screen 1 (Total Hours or Miles)" on page 68

Figure 1-74: Engine Sync No Data Message



"No Data" appears when the Master Node Instrument is not synced to the proper engine number.

### • Single Engine Applications

Single engine applications do not require setting the engine number from which NexSysLink will read CAN Data. The default engine number for single engine applications is 0 (zero) for NMEA 2000® and "ANY" for SAE J1939.


Should a problem exist reading CAN data from an engine due to the engine number, users should set the engine numbers back to the factory settings of 0 (zero) for NMEA 2000® and "ANY" for SAE J1939.

### • Setting SAE J1939 Engine Number

To display data from a vehicle or vessel running multiple engines and using the SAE J1939 protocol, users must sync the Master Node Instrument to the engine number from which it will read CAN data. The diagram below illustrates the steps to set the engine number.

Note: Single engine applications do not require setting the engine number as the factory setting of "ANY" enables reading the engines CAN data.

Figure 1-75: Setting SAE J1939 Engine Number




• Setting SAE J1939 Default Quick View Main Screen 1 (Total Hours or Miles)

When Using the SAE J1939 protocol, users have the option to set Total Hours or Total Miles as the default Quick View Main Screen 1.

See "Default Quick View Main Screen" and "Quick View Main Screens" on page 5.

Figure 1-76: Setting SAE J1939 Default Quick View Main Screen 1



### • Setting Master Node Instrument Instance Number (SAE J1939)

NexSysLink® allows for up to four Master Node Instruments to be connected to a single engine. This is often done when applications require a Master Node Instrument in the cabin or at the helm as well as another location such as the engine compartment or engine room.

When using the SAE J1939 CAN protocol and multiple Master Node Instruments with a single engine, users must set an instance number for each Master Node Instrument in order to read CAN data from the engine. The instance number for each Master Node Instrument must be unique.

Figure 1-77: Setting Master Node Instrument Instance Number



Navigate to the Set CAN Bus Menu, Main Menu-Setup-Set CAN Bus.

Move the selection arrow cursor to the SAE J1939 option and press the Enter switch to select.



The SAE J1939 Menu appears with the selection arrow cursor next to the Engine option.

Press the Down switch to scroll to the Instance option.



With the selection arrow cursor next to the Instance option, press the Enter switch to open the instance number selection screen.



The default Instance number 0 (zero) appears. Press the Enter switch to accept the number or use the Up switch to scroll to the other instance number options. The instance numbers range from 0-4.

**Note:** When using multiple Master Node Instruments with a single engine, each Master Node Instrument connected to the engine must have a unique instance number. A maximum of four Master Node Instruments may be connected to an engine.

### • Setting NMEA 2000® Engine Number

To display data from a vehicle or vessel running multiple engines and using the NMEA 2000® protocol, users must sync the Master Node Instrument to the engine number from which it will read CAN data. The diagram below illustrates the steps to set the engine number.

Note: Single engine applications do not require setting the engine number as the factory settings enable reading the engines CAN data. The default engine number for single engine applications is 0 (zero)

Figure 1-78: Setting NMEA 2000® Engine Number




Navigate to the Set CAN Bus Menu, *Main Menu-Setup-Set CAN Bus.*

The selection arrow cursor appears next to the SAE J1939.

Press the Down switch until the selection arrow cursor is next to the NMEA 2000 option.




With the selection arrow cursor next to the NMEA 2000 option, press the Enter switch to open the NMEA 2000 Menu.



The NMEA 2000 Menu appears with the selection arrow cursor next to the Engine option.

Press the Enter switch to open engine number selection screen.



For multiple engine applications users must choose an engine number from which the Master Node Instrument will read CAN data. The number options range from 0-4.

For single engine applications, users must select engine number 0 (zero).


Use the Up switch to scroll to the other engine number options if necessary. Press the Enter switch to accept the displayed engine number.

### • Setting NMEA 2000® Default Quick View Main Screen 1 (Total Hours or Miles)

When using the NMEA 2000® protocol, users have the option to set Total Hours or Total Miles as the default Quick View Main Screen 1.

See "Default Quick View Main Screen" and "Quick View Main Screens" on page 5.

Figure 1-79: Setting NMEA 2000 Default Quick View Main Screen 1



## • Analog Input Parameters Table

Parameter	Range	Analog Input	LCD Display Name
Block Pressure	0-200 PSI	240-33Ω/10-180Ω	Block Press
Boost Pressure	0-200 PSI	240-33Ω/10-180Ω	Boost Press
Brake Application Pressure	0-200 PSI	240-33Ω/10-180Ω	Brake Appl Pr
Brake Primary Pressure	0-200 PSI	240-33Ω/10-180Ω	Brake Prim Pr
Brake Secondary Pressure	0-200 PSI	240-33Ω/10-180Ω	Brake Sec Prs
Coolant Level	0-100%	240-33Ω/10-180Ω/0-90Ω	Coolant Level
Engine Oil Level	0-100%	240-33Ω/10-180Ω/0-90Ω	Eng Oil Lvl
Engine Oil Pressure	0-200 PSI	240-33Ω/10-180Ω	Eng Oil Press
Front Air Pressure	0-150 PSI	240-33Ω/10-180Ω/0-90Ω	Front Air
Fresh Water Level	0-100%	240-33Ω/10-180Ω/0-90Ω	Fresh Wat Lvl
Fuel Delivery Pressure	0-200 PSI	240-33Ω/10-180Ω	Fuel Press
Fuel Level 1	0-100%	240-33Ω/10-180Ω/0-90Ω/Centroid 3	Fuel Level 1
Fuel Level 2	0-100%	240-33Ω/10-180Ω/0-90Ω/Centroid 3	Fuel Level 2
Generic Level	0-100%	240-33Ω/10-180Ω/0-90Ω	Misc Level
Generic Pressure	0-400 PSI	240-33Ω/10-180Ω	Misc Pressure
Hydraulic Oil Level	0-100%	240-33Ω/10-180Ω/0-90Ω	Hydr Oil Lvl
Hydraulic Oil Pressure	0-200 PSI	240-33Ω/10-180Ω	Hydr Oil Pres
Inside Temperature	-4 - 104 °C	10K Thermistor	Inside Air Tm
Outside Temperature	-4 - 104 °C	10K Thermistor	Outsde Air Tm
Rear Air Pressure	0-150 PSI	240-33Ω/10-180Ω/0-90Ω	Rear Air
Rudder Angle	-100° - 100°	240-33Ω/10-180Ω/0-90Ω	Rudder Angle
Steering Angle	-100° - 100°	240-33Ω/10-180Ω/0-90Ω	Steer Angle
Transmission Oil Level	0-100%	240-33Ω/10-180Ω/0-90Ω	Trns Oil Lvl
Transmission Oil Pressure	0-400 PSI	240-33Ω/10-180Ω	Trns Oil Pres
Trim	0-100%	240-33Ω/10-180Ω/ 0-90Ω/167-10Ω	Trim Position
Washer Fluid Level	0-100%	240-33Ω/10-180Ω/0-90Ω	Washer Level
Waste Water Level	0-100%	240-33Ω/10-180Ω/0-90Ω	Waste Wat Lvl
Water Temperature	-4 - 104 °C	10K Thermistor	Water Temp
GPS Compass	0-360°	NMEA 0183	GPS Compass
GPS Heading	0-360°	NMEA 0183	GPS Heading
GPS Speed	0-200 MPH	NMEA 0183	GPS Speed
Latitude	-180° - 180°	NMEA 0183	Latitude
Longitude	-180° - 180°	NMEA 0183	Longitude
Speed (Water Reference)	0-200 MPH	NMEA 0183	Water Speed
Water Depth	0-999'	NMEA 0183	Water Depth
Water Temperature	-4 - 104 °C	NMEA 0183	Water Temp

• NexSysLink® Implementation of NMEA 2000® Parameters			
Parameter Name	Source	Range	LCD Display Name
Engine RPM	PGN 127488	0-10,000 RPM	Engine Speed
Engine Boost Pressure	PGN 127488	0-400 PSI	Boost Press
Engine Tilt/Trim	PGN 127488	0-100%	Engine Trim
Engine Oil Pressure	PGN 127489	0-400 PSI	Oil Pressure
Engine Oil Temperature	PGN 127489	0-500 °F	Oil Temp
Engine Temperature	PGN 127489	0-500 °F	Engine Temp
Engine Alternator Voltage	PGN 127489	0-100 Volts	Alt Voltage
Engine Fuel Rate	PGN 127489	0-800 GPH	Fuel Rate
Engine Coolant Pressure	PGN 127489	0-400 PSI	Coolant Press
Engine Fuel Pressure	PGN 127489	0-400 PSI	Fuel Pressure
Engine Status Check Engine	PGN 127489	0-1 (Off-On)	Check Engine
Engine Status Over Temperature	PGN 127489	0-1 (Off-On)	Eng Over Tmp
Engine Status Low Oil Pressure	PGN 127489	0-1 (Off-On)	Low Oil Press
Engine Status Low Oil Level	PGN 127489	0-1 (Off-On)	Low Oil Level
Engine Status Low Fuel Pressure	PGN 127489	0-1 (Off-On)	Low Fuel Pres
Engine Status Low System Voltage	PGN 127489	0-1 (Off-On)	Low Voltage
Engine Status Coolant Level	PGN 127489	0-1 (Off-On)	Coolant Level
Engine Status Water Flow	PGN 127489	0-1 (Off-On)	Water Flow
Engine Status Water in Fuel	PGN 127489	0-1 (Off-On)	Water in Fuel
Engine Status Charge Indicator	PGN 127489	0-1 (Off-On)	Charge Indict
Engine Status Preheat Indicator	PGN 127489	0-1 (Off-On)	Preheat Indict
Engine Status High Boost Pressure	PGN 127489	0-1 (Off-On)	Hi Boost Pres
Engine Status Rev Limit Exceeded	PGN 127489	0-1 (Off-On)	Rev Limit Exc
Engine Status EGR System	PGN 127489	0-1 (Off-On)	EGR System
Engine Status Throttle Position Sensor	PGN 127489	0-1 (Off-On)	Throttle Pos
Engine Status Engine Emergency Stop Mode	PGN 127489	0-1 (Off-On)	Eng Emer Stop
Engine Status Warning Level 1	PGN 127489	0-1 (Off-On)	Warn Level 1
Engine Status Warning Level 2	PGN 127489	0-1 (Off-On)	Warn Level 2
Engine Status Power Reduction	PGN 127489	0-1 (Off-On)	Power Reduct
Engine Status Maintenance Needed	PGN 127489	0-1 (Off-On)	Maint Needed
Engine Status Engine Comm Error	PGN 127489	0-1 (Off-On)	Eng Comm Err
Engine Status Sub or Secondary Throttle	PGN 127489	0-1 (Off-On)	Sub Throttle
Engine Status Neutral Start Protect	PGN 127489	0-1 (Off-On)	Neutral Start
Engine Status Engine Shutting Down	PGN 127489	0-1 (Off-On)	Eng Shut Dn
Engine Percent Load	PGN 127489	0-124%	Percent Load
Engine Total Hours	PGN 127489	0-999999 Hours	Total Hours
Engine Percent Torque	PGN 127489	0-124%	Percent Torq
Transmission Oil Pressure	PGN 127493	0-500 PSI	Tran Oil Pres

• NexSysLink® Implementation of NMEA 2000® Parameters			
Parameter Name	Source	Range	LCD Display Name
Transmission Oil Temperature	PGN 127493	0-500 °F	Tran Oil Temp
Transmission Status - Check Transmission	PGN 127493	0-1 (Off-On)	Trans Check
Transmission Status - Over Temperature	PGN 127493	0-1 (Off-On)	Trn Over Tmp
Transmission Status - Low Oil Pressure	PGN 127493	0-1 (Off-On)	Trn Low Oil P
Transmission Status - Low Oil Level	PGN 127493	0-1 (Off-On)	Trn Low Oil L
Transmission Status - Sail Drive	PGN 127493	0-1 (Off-On)	Trans Sail Dr
Transmission Gear	PGN 127493	0-2 (Fwd-N-Rev)	Trans Gear
Rudder Angle	PGN 127245	-180 - 180°	Rudder Angle
Fuel Rate Average	PGN 127497	0-800 GPH	Fuel Rate Avg
Fuel Rate Economy	PGN 127497	0-800 GPH	Fuel Rate Eco
Instantaneous Fuel Economy	PGN 127497	0-800 GPH	Inst Fuel Eco
Level - Fuel	PGN 127505	0-100%	Fuel Level
Level - Fresh Water	PGN 127505	0-100%	Fresh Water
Level - Waster Water	PGN 127505	0-100%	Waste Water
Level - Live Well	PGN 127505	0-100%	Live Well Lvl
Level - Oil	PGN 127505	0-100%	Oil Level
Level - Black Water (Sewage)	PGN 127505	0-100%	Black Water
Battery Voltage	PGN 127508	0-100%	Battery Voltg
Battery Current	PGN 127508	-250 - 250 Amps	Battery Currn
Level - Fuel 2	PGN 127505	0-100%	Fuel Level 2
Level - Fresh Water 2	PGN 127505	0-100%	Fresh Water 2
Level - Waste Water 2	PGN 127505	0-100%	Waste Water 2
Level - Live Well 2	PGN 127505	0-100%	Live Well 2
Level - Oil 2	PGN 127505	0-100%	Oil Level 2
Level - Black Water (Sewage) 2	PGN 127505	0-100%	Black Water 2
Speed (Water Reference)	PGN 128259	0-200 MPH	Water Speed
Speed (Ground Reference)	PGN 128259	0-200 MPH	Ground Speed
Water Depth Transducer	PGN 128267	0-2000 Feet	Water Depth
Water Depth Transducer Offset	PGN 128267	-100 - 100 Feet	Wat Dpth Offs
Latitude	PGN 129025	-90 - 90°	Latitude
Longitude	PGN 129025	-180 - 180°	Longitude
Water Temperature	PGN 130310	-50 - 200 °F	Sea Water
Outside Ambient Air Temperature	PGN 130310	-100 - 200 °F	Outsd Air Tmp
Atmospheric Pressure	PGN 130310	0-100 PSI	Atm Pressure
Port Trim Tab	PGN 130576	0-100%	Port Tab
Starboard Trim Tab	PGN 130576	0-100%	Starboard Tab
Water Pressure	PGN 130314	-400 - 400 PSI	Water Press
Speed Over Ground	PGN 129026	0-200 MPH	GND Speed
Total Cumulative Distance	PGN 128275	0-999999 Miles	Tot Distance

• NexSysLink® Implementation of SAE J1939 Parameters				
Parameter Name	SPN	PGN	Range	LCD Display Name
Accelerator Pedal Position 1	91	61443	0-100%	Accel Pedal %
Engine Air Inlet Pressure	106	65270	0-72 PSI	Air Inlet Prs
Alternator Current	115	65271	0-250 Amps	Alt Current
Charging System Potential	167	65271	0-50 Volts	Alternator
Altitude	580	65256	-1000 - 18,000 Feet	Altitude
Amber Warning Lamp	624	N/A	0-1 (Off-On)	Amb Warn Lmp
Engine Average Fuel Economy	185	65266	0-200 MPG	Avg Fuel Econ
Barometric Pressure	108	65269	0-16 PSI	Barometrc Prs
Net Battery Current	114	65271	-125 - 125 Amps	Battery Curr
Battery Potential/Power Input 1	168	65271	0-50 Volts	Battery Volt
Engine Intake Manifold #1 Pressure	102	65270	0-72 PSI	Boost Press
Brake Application Pressure	116	65274	0-140 PSI	Brake Appl Pr
Brake Primary Pressure	117	65274	0-140 PSI	Brake Prim Pr
Brake Secondary Pressure	118	65274	0-140 PSI	Brake Sec Prs
Aftertreatment 1 SCR Catalyst Reagent Concentration	3516	64923	0-100%	Cat Regnt Con
Aftertreatment 1 SCR Catalyst Reagent Type	3521	64923	0-14	Cat Regnt Typ
Aftertreatment 1 SCR Catalyst Tank Level	1761	65110	0-100%	Cat Tank Lvl
Aftertreatment 1 SCR Catalyst Tank Level 2	3517	65110	0-100%	Cat Tank Lvl2
Aftertreatment 1 SCR Catalyst Tank Temperature	3031	65110	-40 - 400 °F	Cat Tank Temp
Aftertreatment 1 SCR Catalyst Reagent Temperature 2	3515	64923	-40 - 400 °F	Cat Tank Tmp2
Engine Crankcase Pressure	101	65263	-36 - 37 PSI	Cnkcase Press
Compass Bearing	165	65256	0-360°	Compass Bear
Engine Coolant Level	111	65263	0-100%	Coolant Level
Engine Coolant Pressure	109	65263	0-72 PSI	Coolant Press
Engine Coolant Temperature	110	65262	0-400 °F	Coolant Temp
Cruise Control Active	595	65265	0-1 (Off-On)	Cruise Set
Transmission Current Gear	523	61445	-6 - 30 Position	Current Gear
Drive Axle Temperature	578	65273	0-400 °F	Dr Axle Temp
Engine Oil Level	98	65263	0-100%	Eng Oil Level
Engine Oil Pressure	100	65263	0-140 PSI	Eng Oil Press
Engine Oil Temperature 1	175	65262	0-500 °F	Eng Oil Temp
Engine Total Hours of Operation	247	65253	0-999999 Hours	Engine Hours
Engine Speed	190	61444	0-10,000 RPM	Engine Speed
Engine Exhaust Gas Temperature	173	65270	0-3000 °F	Exh Gas Temp















## • NexSysLink® Implementation of SAE J1939 Parameters















Parameter Name	SPN	PGN	Range	LCD Display Name
Fire Apparatus Pump Engagement	2599	61448	0-1 (Off-On)	Fire App Pump
Engine Instantaneous Fuel Economy	184	65266	0-200 MPG	Fuel Economy
Fuel Level 1	96	65276	0-100%	Fuel Level 1
Fuel Level 2	38	65276	0-100%	Fuel Level 2
Engine Fuel Delivery Pressure	94	65263	0-140 PSI	Fuel Pressure
Engine Injector Metering Rail 1 Pressure	157	65243	0-32767 PSI	Fuel Rail 1 Pr
Engine Fuel Rate	183	65266	0-40 GPH	Fuel Rate
Engine Fuel Temperature 1	174	65262	0-400 °F	Fuel Temp
High Resolution Total Vehicle Distance	917	65217	0-999999 Miles	HR Vehicle D
Hydraulic Retarder Oil Temperature	120	65275	0-400 °F	Hyd Rt Oil Tm
Hydraulic Retarder Pressure	119	65275	0-500 PSI	Hyd Rt Press
Hydraulic Oil Level	2602	65128	0-100 PSI	Hydr Oil Lvl
Hydraulic Temperature	1638	65128	0-400 °F	Hydraulic Temp
Cab Interior Temperature	170	65269	-100 - 150 °F	Inside Air Tm
Engine Intercooler Temperature	52	65262	0-400 °F	Intrcoolr Tmp
Latitude	584	65267	-180 - 180°	Latitude
Longitude	585	65267	-180 - 180°	Longitude
Engine Intake Manifold 1 Temperature	105	65270	0-400 °F	Manifold Temp
MIL Lamp	1213	N/A	0-1 (Off-On)	MIL Lamp
Navigation-Based Vehicle Speed	517	65256	0-200 MPH	NAV Speed
Ambient Air Temperature	171	65269	-100 - 200 °F	Outside Air Tm
Parking Brake Actuator	619	65274	0-1 (Off-On)	Park Brake Ac
Parking Brake Switch	70	65265	0-1 (Off-On)	Parking Brake
Engine Percent Load At Current Speed	92	61443	0-120%	Percent Load
Port Trim Tab	N/A (NMEA 2000 Marine)		0-100%	Port Tab
Protect Lamp	987	N/A	0-1 (Off-On)	Protect Lamp
Power Takeoff Oil Temperature	90	65264	0-400 °F	PTO Oil Temp
Power Takeoff Speed	186	65264	0-8000 RPM	PTO Speed
Red Stop Lamp	623	N/A	0-1 (Off-On)	Red Stop Lmp
Road Surface Temperature	79	65269	-100 - 500 °F	Road Temp
Sea Water Pump Outlet Pressure	2435	65172	0-72 PSI	Sea Water Prs
Wheel-Based Vehicle Speed	84	65265	0-200 MPH	Speed
Starboard Trim Tab	N/A (NMEA 2000 Marine)		0-100%	Starboard Tab
Steering Axle Temperature	75	65273	0-400 °F	Steer Axle T
Engine Throttle Position	51	65266	0-100%	Throttle
Tire Location	929	65268	0-255	Tire Location

## • NexSysLink® Implementation of SAE J1939 Parameters















Parameter Name	SPN	PGN	Range	LCD Display Name
Tire Pressure	241	65268	0-140 PSI	Tire Press
Tire Temperature	242	65268	-100 - 250 °F	Tire Temp
Transmission Oil Level	124	65272	0-100%	Trans Oil Lvl
Transmission Oil Pressure	127	65272	0-500 PSI	Trans Oil Prs
Transmission Oil Temperature	177	65272	0-500 °F	Trans Oil Tmp
Trip Average Fuel Rate	1029	65203	0-800 GPH	Trip Avg Fuel
Trip Drive Fuel Economy	1006	65209	0-200 MPG	Trip Fuel Eco
Engine Turbocharger 1 Speed	103	65245	0-250,000 RPM	Turbo 1 Speed
Engine Turbocharger Oil Temperature	176	65262	0-500 °F	Turbo Oil Tmp
Engine Turbocharger Lube Oil Pressure 1	104	65245	0-140 PSI	Turbo Oil
Total Vehicle Distance	245	65248	0-999999 Miles	Vehicle Dist
Total Vehicle Hours	246	65255	0-999999 Hours	Vehicle Hours
Engine Wait to Start Lamp	1081	65252	0-1 (Off-On)	Wait/Strt Lmp
Washer Fluid Level	80	65276	0-100%	Washer Level
Water In Fuel Indicator	97	65279	0-1 (Off-On)	Water in Fuel















• Parameter Icons & Descriptions

Parameter Icon	Description
	Accelerator Pedal Position
	Alternator Current or Voltage
	Altitude
	Atmospheric/Barometric Pressure
	Air Temperature (Inside)
	Air Temperature (Outside)
	Average Fuel Economy
	Battery Voltage or current
	Black Water (Sewage) Level or Waste Water
	Block Pressure
	Boost Pressure
	Brake Application Pressure
	Brake Primary Pressure
	Engine Oil Pressure






Parameter Icon	Description
	Brake Secondary Pressure
	Compass Heading
	Crankcase Pressure
	Cruise Control Active
	Drive Axle Temperature
	Engine Coolant Level
	Engine Coolant Pressure
	Engine Coolant Temperature
	Engine Exhaust Temperature
	Engine Intercooler Temperature
	Engine Manifold Pressure
	Engine Manifold Temperature
	Engine Oil Level
	Hydraulic Oil Temperature









## • Parameter Icons & Descriptions

Parameter Icon	Description
	Engine Oil Temperature
	Engine RPM/Speed
	Fresh Water Level
	Fuel Level
	Fuel Level 2
	Fuel Pressure
	Fuel Rate/Flow Total
	Fuel Temperature
	Gear Pressure
	Gear Temperature
	Hourmeter
	Hydraulic Oil Level
	Road Surface Temperature
	Rudder Angle







Parameter Icon	Description
	Hydraulic Retarder Oil Temperature
	Hydraulic Retarder Pressure
	Instantaneous Fuel Economy
	Latitude
	Live Well Level
	Longitude
	Percent Load
	Percent Engine Torque
	Parking Brake Switch or Actuator
	Power Takeoff Oil Pressure
	Power Takeoff Oil Temperature
	Power Takeoff Speed
	Transmission Gear/ Actual Gear/Current Gear
	Transmission Oil Level






• Parameter Icons & Descriptions

Parameter Icon	Description
SPEED	Speed, Wheel or Water Based
	Steering Angle
STR AXL	Steering Axle Temperature
	Throttle Position
	Tire Pressure
	Tire Temperature
TRIM	Tilt/Trim Position
	Total Engine Hours
Trip	Total Trip Distance
Total	Total Vehicle Distance
Trip MPG	Trip Drive Fuel Economy

Parameter Icon	Description
TRIP FUEL	Trip Fuel
	Transmission Oil Pressure
	Transmission Oil Temperature
	Turbocharger Oil Temperature
	Turbocharger Speed
	Water In Fuel
	Warning
	Washer Fluid Level
DEPTH	Water Depth
	Water Temperature

• Menu Navigation Icon Descriptions

Menu Navigation Icon	Description
	Menu List Identifier
	Selection Arrow Cursor
	Blinking Bar Cursor (Shown under number 0, zero)
	Fault Indicator (Blinks)
	Warning Indicator (Blinks)
	Alarm Indicator (Blinks)

Menu Navigation Icon	Description
	Higher Than Alarm Threshold Indicator
	Lower Than Alarm Threshold Indicator
	Analog to Digital Signal Source Identifier
	No CAN Data Present
	No CAN Data Present

• Notes

## WARRANTY

Beede Electrical Instrument Co., Inc warrants all instruments and accessories free from all defects in workmanship and materials on gauges that are less than three (3) years old or have been in service fewer than two (2) years and, at no charge, will replace or repair at Beede's option all instruments that fail. Contact Beede for complete details.

---

## THANK YOU!

Thank you for purchasing a Beede® Instrument.  
Our instruments are designed and manufactured for you in the U.S.A.  
Visit our web site at [www.beede.com](http://www.beede.com)  
or contact customer service for information  
on this or other Beede® instruments.